



lähimmästä

		Kytkinlevy I										Kytkinlevy II										Kytkinlevy III																
Aaltoaluekytkin		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	
Alue	kHz																																					
IV	3000 ... 6000	•																																				
III	1300 ... 3600																																					
II	485 ... 1415																																					
I	150 ... 435																																					

**VIESTIKOULU**

VREH ja VREHB:n vastaanotin

N<sup>o</sup>655C6

Piirt. M. J. 10.3.-56  
 Tark. J. V. 15.3.56  
 Myy. J. U. 15.3.56